

FOLD LINE

CUT 7
ADD 1/2" SEAM ALLOWANCE
ON ALL SIDES

Asian Ottoman Floor Cushion Wedge Pattern

Scale
1" = 1"

IMPORTANT: Print this
.pdf file actual size; do not
size or scale to fit page.

sew4home™
Transform your space.