



TOP

Place on fold

Place on bottom finished edges

This pattern is for a standard Bodum French Press measuring 6 1/2" high x 1 47/8" around with a 4 1/2" handle opening. A seam allowance of 3/8" is included in the pattern.

Test this pattern on your own French Press by cutting it out and wrapping it around and through the handle, remembering that 3/8" will be taken up all around. Too big? Fold it down to fit and tape in place. Too small? Measure by how much, and then redraw around the pattern onto a larger sheet of paper, adding the extra amount to all sides. As always... remembering to add in 3/8" for the seams.

Place on bottom finished edges

Place on fold

